

# ENDUREPEL MCCOY FUNDAMENTALS II

Fabrics » Woven Fabrics

---



Brand: **Endurepel**

1300 306 399

[info@baresque.com.au](mailto:info@baresque.com.au)

[baresque.com.au](http://baresque.com.au)

1 of 5

# ENDUREPEL MCCOY FUNDAMENTALS II

Fabrics » Woven Fabrics

---



61 STUCCO



62 COPPER



84 BARK



91 PLATINUM



94 MERCURY



108 CORDOVAN



305 NAVY



601 CREME



608 TUNDRA

# ENDUREPEL MCCOY FUNDAMENTALS II

Fabrics » Woven Fabrics

Mccoys is a stain-resistant fabric with anti-microbial protection that's available in 9 colourways. Optional upgrade for complete moisture barrier.

✓ **Moisture Repellant**

✓ **Anti-Bacterial**

✓ **Anti-Microbial**

**Description** The Fundamentals II range features 85 coordinating textures and semi-plains that come standard with Endurepel Shield performance finish to repel liquid and make the upholsteries anti-microbial and anti-bacterial. Add Endurepel Barrier for a complete moisture barrier.

**Roll Size** 137cm x Approx 45m - 55m - Available by the lineal metre

**Composition** Endurepel Shield - 100% polyester Add Endurepel Barrier for a complete moisture barrier

**Abrasion** 50,000+ Double Rubs (Wyzenbeek)

**Pattern Repeat Size** N/A

**Fire Rating** Tested in accordance with AS1530.3  
Spread of Flame Index - 0  
Smoke Developed Index - 4

**Warranty** 2-year warranty. Visit [baresque.com.au/warranty](https://baresque.com.au/warranty) for complete details.

**Lead Time**

- 3-weeks (approx) from Wednesday subject to stock availability.
- Additional 1-week for Western Australia.
- Additional 2 weeks for Endurepel Barrier.
- Express delivery is available subject to a surcharge. Contact Baresque for details and pricing.

# ENDUREPEL MCCOY FUNDAMENTALS II

Fabrics » Woven Fabrics

---

## Care Instructions

Always use a clean, white, soft cloth.

Clean in situ using a damp cloth and mild detergent. Sponge down afterwards with a clean, damp cloth.

Using a cloth to pat dry will help eliminate watermarks.

Ensure the pile is brushed back to its natural direction.

Upholstered furniture should be regularly vacuumed or brushed with a soft nylon brush to remove grit or dust, which may damage the pile.

Never use stiff bristles or wire brushes, as they may damage the fabric.

Always test in an inconspicuous area first. If care instructions don't deliver the expected results, cease cleaning method immediately and contact Baresque for assistance.

---

## Additional Comments

Add Endurepel Barrier for full Moisture Barrier

---

# ENDUREPEL MCCOY FUNDAMENTALS II

Fabrics » Woven Fabrics

---

## Colour & Finish Options