

CHERRY

Digital Print » Premium Wood Print



Brand: **Zintra**

CHERRY

Digital Print » Premium Wood Print



CHERRY

CHERRY

Digital Print » Premium Wood Print

Rich red to reddish brown tones containing some brown pith flecks

Description

Premium Wood Print offers a realistic alternative to real wood when creating warm, inviting, and acoustically minded commercial spaces. We've sourced twelve artisan species from the US and around the world, to complement the latest contract furniture trends, with grains that go from mild to wild.

Designed to bring the outdoors in, Premium Wood Prints help create calming spaces that connect people with nature.

Premium Wood is printed on a colored base, which has been expertly matched to complement the Premium Wood species, ensuring minimal edge contrast and seamless integration.

Providing a clean, crisp aesthetic with the most accurate color matching available in 1/2" (12mm).

Made to order realism with high resolution photography, printed single or double sided.

NRC 0.45 - 0.95

Dimensions

Available in 1/2" (12mm)

Base Color ECRU only

48.2" (1225mm) w x 110.3" (2800mm) h x 1/2" (12mm) d

Composition

Zintra Acoustic Panel - 100% Solution Dyed (Color Through) Polyester

Environmental Info

Easily recycled through standard recycling channels

Fire Rating

Tested in accordance with AS ISO 9705 2003 for the purpose of determining the Group Number classification required by the Building Code of Australia for the control of fire spread on interior wall and ceiling linings.

Classification - Group 1

Specific Extinction - Less than 250m²/kg

Warranty

5-year warranty. Visit baresque.com.au/warranty for complete details.

Assembly & Delivery

Ships Flat Pack

Refer installation Instructions

CHERRY

Digital Print » Premium Wood Print

How to Specify

1. Select Premium Wood Color
2. Qty

Care Instructions

Vacuum to remove dust.

Dab Zintra with a damp clean cloth and mild solution of liquid detergent and warm water. Repeat using only clean water, then pat dry with a lint free cloth.

For difficult stains, use a solution of household bleach (10% bleach / 90% water). To remove the bleach, repeat using a clean, water dampened cloth, then pat dry.

Always test in an inconspicuous area first and if you don't see the expected results, contact us.

Additional Comments NRC 0.45 - 0.95

CHERRY

Digital Print » Premium Wood Print

Colour & Finish Options