**Fabrics** » Vinyl and Faux Leather Fabrics



Brand: Concertex

Collection: Dimensional



Fabrics » Vinyl and Faux Leather Fabrics

# COLOURWAY CARD









COLOURWAY CARD





SAPPHIRE

LINEN

MATCHA

PALLADIUM

PERSIMMON



Fabrics » Vinyl and Faux Leather Fabrics



Wavelegth-Dimensional is a padded faux leather coated fabric embossed with a wave pattern that's available in 9 colours.

Bleach Cleanable	Moisture Barrier	Anti-Bacterial
Description	Perfect for bedheads or upholstered booth seating, DIMENSIONAL is a revolutionary, padded faux leather created by an ultrasonic sealing process. It is impervious to moisture and has extreme depth for 3 dimensional look while flexible enough for easy upholstering. The faux leather surface passes over 100,000 double rubs and contains a built-in graffiti-free layer for stain-free atmosphere. Stains and ballpoint pen marks can easily be wiped away with just a dry towel. Bleach solution can also be used.	
Roll Size	137cm x 18.3m - Available by the lineal metre.	
Composition	100% polyurethane on a 100% polyester backing	
Abrasion	100,000 + double rubs Wyzenbeek	
Pattern Repeat Size	17.5cm H x 3cm V	



Fabrics » Vinyl and Faux Leather Fabrics

**Environmental Info** PVC free

Phthalate Free

**DMF Free** 

No added fire retardant

Anti-Bacterial

Healthier Hospitals compliant

Complies with CAL01351

Tested in accordance with AS1530.3 Fire Rating

Spread of Flame Index - 0

Smoke Developed Index - 5

Warranty 2-year warranty. Visit baresque.com.au/warranty for complete details.

Lead Time • 2-weeks (approx.) from Wednesday, subject to stock availability.

• Additional 1-week for Western Australia.

• Express delivery is available subject to a surcharge. Contact Baresque for details

and pricing.

Most stains and ballpoint pen marks can be removed with a clean dry towel. Care Instructions

> Wipe material with a clean, soft cloth dampened with a mild solution of liquid detergent and warm water. Repeat using only clean water, then dry with a lint free

cloth.

Avoid using wax polishes, solvents or concentrated abrasives.

For more difficult stains, dampen a soft white cloth with a solution of household bleach (5:1). Rub gently. Rinse with a water dampened cloth to remove bleach

concentration.

Always test in an inconspicuous area first. If care instructions don't deliver the expected results, cease cleaning method immediately and contact Baresque for

assistance.

Additional Comments Wavelength should only be stapled. Do not use adhesives on this product as

adhesives seeping into the padding will deform the natural shape. Vita is the

matching plain to this design.

