

MATTE RITE

Wallcoverings » Writable and Magnetic Wallcoverings




Brand: **Koroseal**

MATTE RITE


Wallcoverings » Writable and Magnetic Wallcoverings



MA50 (adhesive backed)



MP50 (non-woven backed)



MP60 (non-woven backed)

MATTE RITE

Wallcoverings » Writable and Magnetic Wallcoverings



High-quality, matte to semi-gloss dry erase surface. Comes in flexible rolls with fabric backing and installs like most commercial wallcoverings.

Description	<p>Combining the functionality of a writable and projection surface, walltalkers Matte Rite is the perfect solution for applications requiring a dry erase writing surface and projection surface.</p> <p>Using a smooth, non-glare film, Matte Rite should be specified when the wallcovering will be used for projections 50% of the time and writing 50% of the time.</p>
Product Code	WC.MATTE-RI.MA50
Roll Size	MP60 - 150/152cmMP50 - 124/127cmMA50 - 124/127cm (adhesive backing) x 30.5m Available by the lineal metre.
Composition	Vinyl with non woven or adhesive backing
Warranty	2-year warranty. Visit baresque.com.au/warranty for complete details.

MATTE RITE

Wallcoverings » Writable and Magnetic Wallcoverings

Lead Time	<ul style="list-style-type: none">• 2-weeks (approx.) from Wednesday, subject to stock availability.• Additional 1-week for Western Australia.• Express delivery is available subject to a surcharge. Contact Baresque for details and pricing.
Suggested Installation	<p>Can be hung vertically or horizontally.</p> <p>Reverse hang, overlap and double cut.</p> <p>Baresque recommends and supplies Roman brand adhesives and primers.</p>
Care Instructions	<p>Remove dry erase markings with a microfiber cloth. Press firmly in a circular motion.</p> <p>Wash cloth or change erasers as they become dirty as dirty dry erase cleaning cloths and erasers will spread ink residue on the surface.</p> <p>For daily cleaning, or as required, rinse the surface with water.</p> <p>Dry the surface with a soft cloth prior to writing.</p> <p>See Walltalkers Care Maintenance pdf for full instructions.</p> <p>Always test in an inconspicuous area first. If care instructions don't deliver the expected results, cease cleaning method immediately and contact Baresque for assistance.</p>
Additional Comments	<p>All Walltalker products should be washed with an ammonia or alcohol-based cleaner or mild soap and rinsed thoroughly with water prior to using. See Walltalkers Care Maintenance pdf for full details</p>