Fabrics » Vinyl and Faux Leather Fabrics



Brand: Concertex

Collection: Dimensional



Fabrics » Vinyl and Faux Leather Fabrics





Fabrics » Vinyl and Faux Leather Fabrics

Divergent is a 132cm wide padded faux leather impervious to moisture easily cleaned with just a dry towel that's available in 9 colours

✓ Bleach Cleanable	✓ Moisture Barrier	✓ Anti-Bacterial
Description	Perfect for bedheads or upholstered booth seating, DIMENSIONAL is a revolutionary, padded faux leather created by an ultrasonic sealing process. It is impervious to moisture and has extreme depth for 3 dimensional look while flexible enough for easy upholstering. The faux leather surface passes over 100,000 double rubs and contains a built-in graffiti-free layer for stain-free atmosphere. Stains and ballpoint pen marks can easily be wiped away with just a dry towel. Bleach solution can also be used.	
Roll Size	138cm x N/A - Available by the lineal metre. MINIMUM ORDER 5 METRES	
Composition	100% polyurethane on a 100% polyester backing	
Abrasion	100,000 + double rubs Wyzenbeek	
Pattern Repeat Size	24.4cm H x 22cm V	
Environmental Info	PVC free	
	Phthalate Free	
	DMF Free	
	No added fire retardant	
	Anti-Bacterial	
	Healthier Hospitals compliant	
	Complies with CAL01351	
Fire Rating	Tested in accordance with AS1530.3	
	Spread of Flame Index - 0	
	Smoke Developed Index - 5	
Warranty	2-year warranty. Visit <b>baresque.com.au/warranty</b> for complete details.	



Fabrics » Vinyl and Faux Leather Fabrics

Lead Time	<ul> <li>2-weeks (approx.) from Wednesday, subject to stock availability.</li> <li>Additional 1-week for Western Australia.</li> <li>Express delivery is available subject to a surcharge. Contact Baresque for details and pricing.</li> </ul>
Care Instructions	Most stains and ballpoint pen marks can be removed with a clean dry towel. Wipe material with a clean, soft cloth dampened with a mild solution of liquid detergent and warm water. Repeat using only clean water, then dry with a lint free cloth. Avoid using wax polishes, solvents or concentrated abrasives. For more difficult stains, dampen a soft white cloth with a solution of household bleach (5:1). Rub gently. Rinse with a water dampened cloth to remove bleach concentration. Always test in an inconspicuous area first. If care instructions don't deliver the expected results, cease cleaning method immediately and contact Baresque for assistance.
Additional Comments	Divergent should only be stapled. Do not use adhesives on this product as adhesives seeping into the padding will deform the natural shape.



Fabrics » Vinyl and Faux Leather Fabrics

**Colour & Finish Options** 

